

IRIS Touch Firmware Enhancements and Additions from Version 1.12.5 to Version 1.12.6

Overview

This document details enhancements to the feature set of the IRIS Touch from firmware Version 1.12.5 to Version 1.12.6.

This release (V1.12.6) is available on Chiron's reflash server with immediate effect. Due to normal manufacturing lead times, it will be introduced into new shipments over the course of the next few months. However, all IRIS Touch diallers can be upgraded by connecting them over IP to our reflash server, so you can be sure of having all the latest facilities, even if you have already taken delivery of the dialler. This can be done prior to install, at install or even after install.

IRIS Touch diallers have always worked very effectively with Honeywell Galaxy panels, connected either via the dial capture port or the RS485 bus. A situation has been identified recently where in a limited number of cases an upgrade of the Touch dialler is required, but only when the following three conditions *all* apply:

- Alarms are transmitted from the Galaxy panel via the RS485 bus.
- *And* the dialler is being used for dual path signalling with an Ethernet VPN, rather than Ethernet via the Internet.
- *And* the dialler has software version fitted from Version 1.11 to 1.12.5.

Diallers connected to the alarm panel via the dial-capture interface, or version 1.9.5 or earlier are not affected.

As a precaution, Chiron recommend that *all* Touch diallers between versions 1.11 and V1.12.5 that operate with a connection to the RS485 bus of a Honeywell Galaxy alarm panel are upgraded to this new releases when the opportunity arises.

Chiron Security Communications Ltd

Wyvols Court, Swallowfield, Reading
Berkshire RG7 1WY, United Kingdom
Telephone: +44 0118 988 0228
Facsimile: +44 0118 988 1055
www.chironsc.com
Email: sales@chironsc.com

Registered office number: 6031811
2nd Floor, Aqus House, 49-51 Blagrove Street
Reading, Berkshire RG1 1PL United Kingdom

Chiron Security Communications Ltd
part of the Chi Holding group of companies 



How to Reflash

Connection to the reflash server can be instigated from the installer menu, Settings->Reflash:



The reflash IP address is set by default to Chiron's reflash server (195.59.117.164) and does not need to be changed unless another reflash server is to be used.